


Quick Installation Guide for Camera Plate C2




Camera Plate C2 works for cameras compatible with Canon BG-E3, BG-E5, BG-E8 or BG-E9. These include Canon 60D, 350D, 400D, 450D, 500D, 550D, 600D, 1000D.



Optional Feature:
If the QR clamp being used does not have a safety pin, you can use the M3 Safety Stop Screws. Install the M3 screws at each end of plate making sure to use the black plastic washers as spacer.



Install the anti-twisting pin to the appropriate position according to the number prescribed below. Then carefully align it to the corresponding socket at the camera base. Tighten the 1/4" screw slowly while keeping the pin in alignment. Be careful not to overtighten. Check that the camera plate sits snugly to the camera base when finished.



Position 1:

cameras compatible with BG-E9 e.g. Canon 60D.

Position 2:

cameras compatible with BG-E8 e.g. Canon 550D, 600D.

Position 3:

cameras compatible with BG-E5 e.g. Canon 450D, 500D, 1000D.

Position 4:

cameras compatible with BG-E3 e.g. Canon 350D, 400D.